



# Ergotron® LX

## Sit-Stand Wall Mount System


Dimensional &  
Range of Motion  
Illustrations




### Small CPU Holder




### Medium CPU Holder



### Wall Mount Bracket



### Wall Track



© 2013 Ergotron, Inc. rev. 02/05/2013 DIM-LXSSWMSsystem Content is subject to change without notification

#### Americas Sales and Corporate Headquarters

St. Paul, MN USA  
(800) 888-8458  
+1-651-681-7600  
www.ergotron.com  
sales@ergotron.com

#### EMEA Sales

Amersfoort, The Netherlands  
+31 33 45 45 600  
www.ergotron.com  
info.eu@ergotron.com

#### APAC Sale

Tokyo, Japan  
www.ergotron.com  
apaccustomerservice@ergotron.com

#### Worldwide OEM Sales

www.ergotron.com  
info.oem@ergotron.com




# Ergotron® LX



## Sit-Stand Wall Mount System

Dimensional & Range of Motion Illustrations


### LCD Arm




### Dimensions



### Range of Motion



### Weight Capacity



Monitor depth greater than 2.5" (64 mm) may diminish capacity. Call Ergotron for more information.

© 2013 Ergotron, Inc. rev. 02/05/2013 DIM-LXSSWmsystem Content is subject to change without notification

#### Americas Sales and Corporate Headquarters

St. Paul, MN USA  
(800) 888-8458  
+1-651-681-7600  
www.ergotron.com  
sales@ergotron.com

#### EMEA Sales

Amersfoort, The Netherlands  
+31 33 45 45 600  
www.ergotron.com  
info.eu@ergotron.com

#### APAC Sale

Tokyo, Japan  
www.ergotron.com  
apaccustomerservice@ergotron.com

#### Worldwide OEM Sales

www.ergotron.com  
info.oem@ergotron.com



# Ergotron® LX



## Sit-Stand Wall Mount System

Dimensional &  
Range of Motion  
Illustrations


### Keyboard Arm






#### Dimensions



#### Weight Capacity



#### Range of Motion



© 2013 Ergotron, Inc. rev. 02/05/2013 DIM-LXSSWsystem Content is subject to change without notification

#### Americas Sales and Corporate Headquarters

St. Paul, MN USA  
(800) 888-8458  
+1-651-681-7600  
www.ergotron.com  
sales@ergotron.com

#### EMEA Sales

Amersfoort, The Netherlands  
+31 33 45 45 600  
www.ergotron.com  
info.eu@ergotron.com

#### APAC Sale

Tokyo, Japan  
www.ergotron.com  
apaccustomerservice@ergotron.com

#### Worldwide OEM Sales

www.ergotron.com  
info.oem@ergotron.com

